BRIO - 300Lx



SELF SERVICE TERMINAL

USER MANUAL

 ϵ

© BRIO SRC, SIA. All rights reserved. BRIO EngineerinG ©, BRIO SRC, logo BRIO SRC, logo BRIO EngineerinG, BRIO-300Lx, are registered trademarks of BRIO SRC, SIA



CONTENTS:

- 1 HOW TO PAY FOR THE FUEL?
- 2 PAYMENT WITH CORPORATE CARD
 - 2.1 INSERT CARD 2.2 CHOOSE PUMP Nr. 2.3 CHOOSE FUEL
 - 2.4 ENTER PIN-CODE 2.5 PRINT RECEIPT
- 3 PAYMENT WITH BANK CARD
 - 3.1 INSERT CARD 3.2 CHOOSE PUMP Nr. 3.3 CHOOSE FUEL
 - 3.4 ENTER PIN-CODE 3.5 INSERT DISCOUNT CARD 3.6 PRINT RECEIPT
- 4 PAYMENT WITH CASH
 - 4.1 INSERT BANKNOTE 4.2 CHOOSE PUMP Nr. 4.3 CHOICE FUEL
 - 4.4 INSERT DISCOUNT CARD 4.5 PRINT RECEIPT
 - 4.6 PRINT CANCELLATION RECEIPT 4.7 FUEL TOP-UP FUNCTION
- 5 CANCEL ORDER
 - 5.1 AUTOMATIC CANCEL 5.2 FORCED CANCEL




SELECT TOPIC: 1,2,3.





BRIO SRC BRIO-300Lx



USER MANUAL 3 / 17

BRIO SRC

2 PAYMENT WITH CORPORATE CARD

2.1 INSERT CORPORATE CARD

- Insert your corporate card into the reader as shown on the picture.
 - If the card was inserted correctly, reader will drag it inside.



Reader status is shown by LED color:

- Ready
- Not ready
- There is a card in the reader








USER MANUAL 4 / 17

2 PAYMENT WITH CORPORATE CARD

2.2 CHOOSE PUMP Nr.

 Choose the Pump by pushing the key on the side keyboard





2.3 CHOOSE FUEL TYPE

 Choose fuel type by pressing function key on the display's side keyboard.









To cancel the selection use the proper function key on the display's side keyboard.



USER MANUAL 5 / 17

PAYMENT WITH CORPORATE CARD


2.4 ENTER PIN-CODE

 Enter PIN-code for corporate card by using special keyboard.

CANCEL - Delete entered code.

- Delete last digit. CLEAR

- Confirm entered code. ENTER



Take Your card. Now you can fill the tank.











2 PAYMENT WITH CORPORATE CARD

2.5 PRINT RECEIPT

 After filling the tank, put back the pistol and insert the corporate card once more into the reader.





 The receipt will be printed, and the reader will return the card. Please, take your receipt and card.











USER MANUAL 7 / 17


3.1 INSERT YOUR BANK CARD


 Insert your bank card into the reader as shown on the picture.



3.2 CHOOSE PUMP Nr.

 Choose the Pump by pushing the key on the side keyboard.







USER MANUAL 8 / 17

3.3 CHOOSE FUEL TYPE

 Choose fuel type by pressing function key on the display's side keyboard.






To cancel the selection use the proper function key on the display's side keyboard.

3.4 ENTER PIN-CODE

 Enter PIN-code of the bank card by using bankcard terminal's keyboard.








 If the PIN-code is correct, the display will show the message to enter the discount card.






3.5 INSERT DISCOUNT CARD

- Insert your discount card into reader as shown on the picture.
 - If the card will be entered correctly, reader will drag it inside.





Please, take your card. Now you can fill the tank.













3.6 PRINT RECEIPT

 After filling the tank, place back the pistol and insert the bank card once more into the reader.





The receipt will be printed, and the reader when the card.
Please, take out your receipt and card.











USER MANUAL 11 / 17

4.1 INSERT BANKNOTES

 Start to insert banknotes into the slot as shown on the picture.

Please, insert the banknotes one by one.
 After each banknote the display will show it's value and the total amount.

Wrinkled, dirty and damages banknotes may not be accepted by the terminal!

Press the key [Next] on the display's side keyboard, when finished.








4.2 CHOOSE PUMP Nr.

 Choose the Pump by pushing the key on the side keyboard.





4.3 CHOOSE FUEL TYPE

 Choose fuel type by pressing function key on the display's side keyboard.










To cancel the selection use the proper function key on the display's side keyboard.



4.4 INSERT DISCOUNT CARD

- Insert the discount card into reader as shown on the picture.
 - If the card is inserted correctly, reader will drag it inside.





4.5 PRINT RECEIPT

- If all is correct, machine will print the receipt and return your card.
- Please, take your card and receipt. Now you can fill the tank.











4.6 PRINT CANCELLATION RECEIPT


- If the fuel ordered, wasn't delivered fully (tank was full, pump was damaged etc.), you can refund the money, only if you have the printed Cancellation Receipt.
 - Terminal will not return the cash!
- Put back the pistol, go to the terminal and press [Refund] on display's side keyboard.
- Enter the ID-code of the Receipt that was printed before refueling.



1,2,3...ENTER









Use Fuel Top-up Function (4.7) or contact the administration. Be ready to present the Cancellation Receipt.

USER MANUAL 15 / 17


4.7 FUEL TOP-UP FUNCTION

 To use the Fuel Top-up Function, press the [Return] key on the side keyboard.



Enter the ID-Code of the Cancellation Receipt.









The display will show the unused amount, which can be used for the fuel top-up and two buttons: [Cancel] and [Continue].



 You can continue refueling, as described in 4.2 - 4.7 chapter, or cancel the Top-up Function.



5 CANCEL ORDER

5.1 AUTOMATIC CANCEL IF FUELLING WASN'T STARTED

 If the fuel was ordered, but refilling not yet started (The pistol wasn't taken off the cradle) - after 5 minutes your order will be canceled automatically.



5.2 FORCE CANCEL IF FUELLING WASN'T STARTED (Not for gas refilling stations!)

- If the fuel was ordered, but refilling not yet started, you can cancel the order, by:
 - Take off the pistol.
 - Wait for pump to start (you can here the sound)
 - Put back the pistol. Your order will be canceled.









If the order was paid by cash, please go to the terminal and print the Cancellation Receipt.

USER MANUAL 17 / 17